

Operating Instructions

EMGZ492.ECAT

Dual channel measuring amplifier for EtherCAT®

EMGZ492.R.ECAT for mounting on DIN rail

EMGZ492.W.ECAT for wall mounting

Dokument Version Firmware Version ESI Datei 1.5 11/2024 NS V 2.0.4 FMS_TensionAmplifier_EMGZ49X.xml



Diese Bedienungsanleitung ist auch in Deutsch erhältlich. Bitte kontaktieren Sie Ihre lokale FMS Vertretung.

EtherCAT[®] is a registered trademark and patented technology, licensed by Beckhoff Automation

© by FMS Force Measuring Systems AG, CH-8154 Oberglatt – All rights reserved. GmbH, Germany.





1 Table of Contents

1	TABLE OF CONTENTS	2
2	SAFETY INFORMATION	4
	 2.1 Presentation of Safety Information	4 4 4 5
3	PRODUCT DESCRIPTION	6
4	 3.1 Block Diagram	6 6 6
	 4.1 Preparations for Parameterization	8 8 9 9 9 9 10 11
5	CALIBRATION OF THE MEASURING SYSTEM	12
	 5.1 Offset Compensation	12 12 13 13 14 14 15 15
6	INTEGRATION INTO THE ETHERCAT [®] NETWORK	16
	 6.1 EtherCAT[®] Interface	16 16 16
7	CONFIGURATION	17
	 7.1 Parameter Description 7.2 Cyclic Data Traffic 7.3 Acyclic Data Traffic 	17 20 24
8	ETHERCAT [®] COMMUNICATION	31
	8.1 Services and Protocols	31
9	DIMENSIONS	32



10	TECHNICAL DATA	3
----	----------------	---

2 Safety Information

All safety information, operating and installation regulations listed here ensure proper function of the device. Safe operation of the systems requires compliance at all times. Noncompliance with the safety information or using the device outside of the specified performance data can endanger the safety and health of persons.

Work with respect to operation, maintenance, retrofit, repair, or setting the device described here must only be performed by expert personnel.

2.1 Presentation of Safety Information

2.1.1 Danger that Could Result in Minor or Moderate Injuries



Danger, warning, caution Type of danger and its source Possible consequences of nonobservance Measure for danger prevention

2.1.2 Note Regarding Proper Function



Note

Note regarding proper operation Simplification of operation Ensuring function



2.2 General Safety Information



The function of the measuring amplifier is only ensured with the components in the specified layout to one another. Otherwise, severe malfunctions may occur. Thus, observe the mounting information on the following pages.



Observe the local installation regulations.



Improper handling of the electronics module can lead to damage to the sensitive electronics!

Do not work with a blunt tool (screw driver, pliers, etc.) on the housing!

Use suitable grounding (grounding wrist strap, etc.) when working on the electronics.



The devices should have a distance of at least 15 mm to one another in the control cabinet for proper cooling.



3 Product Description

3.1 Block Diagram



Figure 1: EMGZ492.ECAT block diagram

EMGZ492_ECAT_BA_Manual.ai

3.2 System Description

The microprocessor-controlled measuring amplifier EMGZ492.ECAT series is used in processing, amplifying, and relaying sensor signals in suitable form to downstream devices. The measured force values are available via EtherCAT[®] and an analog voltage output.

The measuring amplifiers are suitable for tension measurements using all FMS load cells. Two force sensors A and B can be connected to the device. Both measuring values are available as individual signal (A and B), as sum signal (A + B), as differential signal |A - B| or as average value (A + B)/2 for the master controller.

3.3 Scope of Delivery

The following is included in the scope of delivery

- Measuring amplifier
- Mounting and operating instructions

The following is not included in the scope of delivery

- AC/DC power supply, minimum requirement: EMC immunity specifications EN61000-4-2, 3, 4, 5; EN55024 light industry level, criteria A, e.g., TRAKO TXL 035-0524D
- Cable for power supply

The following is not included in the scope of delivery, but are available as accessories from FMS

- Patch cable with RJ45 plug (straight or 90°)
- Sensor cable for the connection of load cell and measuring amplifier



- M12 plug, D-coded



In these operating instructions, commissioning of the EMGZ492.ECAT amplifier is limited to the installation procedure, offset compensation, and system calibration.

4.1 Preparations for Parameterization

- Read the operating instructions of the selected load cell carefully.
- Check your requirements on the system, such as:
 - Used units in the system
 - Used outputs (-10 to 10V and bus)
- Filter settings for actual force value and analog output
- Create the connection diagram for your specific system layout (see chapter "Electrical Connection")

4.2 Mounting Sequence

- Mount the load cells (mounting details can be obtained from the mounting instructions of the load cells)
- Connect the load cells to the amplifier (see 4.5)
- Connect the amplifier to the supply voltage. The voltage supply must be in the range of 18 to 36 VDC. (See 4.5)
- Perform offset compensation and calibration (see 5.1 and 5.3)
- Change the parameter settings as needed (see 7)
- Amplifier integration into the EtherCAT[®] network (see 8)

4.3 Mounting and Electrical Connections





To improve natural convection and keep heating of the amplifiers as low as possible, the devices installed in a cabinet should have a minimum distance of 15 mm.





The function of the measuring amplifier is only ensured with the components in the specified layout to one another. Otherwise, severe malfunctions may occur. Thus, the mounting information on the following pages must be followed





The local installation regulations ensure the safety of electrical systems. They are not considered in these operating instructions.



However, they must be met.

4.4 Load Cell Mounting

The load cells are mounted in line with the mounting instructions of the respective products. The mounting instructions are included with the load cells.

4.5 Electrical Connections

Two or four load cells can be connected to the EMGZ492.ECAT. When four sensors are used, two of them have to be connected in parallel. The load cells and amplifier are connected using a 2x2x0.25 mm² [AWG 23] shielded, twisted cable.

13	14 15 16	Spa	nnungsversorg.	Kra	aftaufnehmer 1	Kraf	taufnehmer 2	Anal	ogausgang
9		1	24 VDC	5	+ Speisung	9	- Speisung	13	± 10 V
	-MS•)	2	GND	6	+ Signal	10	– Signal	14	GND
ο λ ο	çıfta 5	3	PE	7	– Signal	11	+ Signal	15	n.a.
R		4	Schirmung	8	– Speisung	12	+ Speisung	16	Schirmung
RUN 🔶		Po	wer Supply	Lo	ad Cell 1	Loa	d Cell 2	Ana	log Output
R 🔹 RUN 🔵		Po	wer Supply 24 VDC	Lo 5	ad Cell 1 + Excitation	Loa 9	d Cell 2	Ana 13	log Output ± 10 V
ERR 🌒 RUN 🌒		Po 1 2	24 VDC GND	Lo 5	ad Cell 1 + Excitation + Signal	Loa 9 10	d Cell 2 - Excitation - Signal	Ana 13 14	log Output ± 10 V GND
ER • RUN •		Po 1 2 3	24 VDC GND PE	Lo 5 6 7	ad Cell 1 + Excitation + Signal - Signal	Loa 9 10 11	d Cell 2 - Excitation - Signal + Signal	Ana 13 14 15	log Output ± 10 V GND n.a.



Figure 2: EMGZ492.R.ECAT electrical connections

FMS_

For easier installation, the terminal blocks can be detached from the main housing.



Figure 3: Detachable terminal blocks: use a small slotted screwdriver as a lever

4.5.2 EMGZ492.W.ECAT

The 4 screws of the cover with the PG glands and the M12 plug must be loosened for board access. You can slide out the board by approx. 2 cm (1 in.) and loosen the terminal blocks for easier connection of the wires.



Figure 4: Pc board with removable terminal blocks EMGZ492_W_PNET_16-11.30.FCStd



Figure 5: EMGZ492.W.ECAT electrical connections



4.5.3 Ethernet Connections

Signal	Name	EtherCAT®	EIA T568B	Pin RJ45	Pin M12
TD+	Transmission Data +	YE	WH/OG	1	1
TD-	Transmission Data -	OG	OG	2	3
RD+	Receive Data +	WH	WH/GN	3	2
RD-	Receive Data -	BU	GN	6	4

Table 1: pin assignment Ethernet connection

EMGZ492_ECAT_Grafik.ai



Warning

Poor grounding can result in electric shocks for persons, malfunctions of the overall system or damage to the measuring amplifier! Proper grounding must always be ensured.



Note

Cable shielding may only be connected to one side of the measuring amplifier. On the side of the load cell, shielding must remain open.



5 Calibration of the Measuring System

5.1 Offset Compensation

Using offset calibration, the weight of the measuring roller and the roller bearings is compensated and the measuring system "zeroed".

Offset compensation must always be executed prior to the actual calibration. The measuring roller must not be loaded during the procedure.

To change the values for the offset compensation, please refer to 7.3 Acyclic Data Traffic.

5.2 Calibration in the Amplifier (Adjusting the Gain Factor)

Calibration is used for matching the gain factor with the load cells. After calibration, the displayed force corresponds to the force effectively affecting the material. Two calibration methods are available. The first calibration method described here uses a defined weight. There is also a calculation method for the gain. The weight-based calibration method is simple and delivers more accurate results as it replicates the material profile (see the figure below) and considers the actual circumstances in the machine.



Figure 6: Replication of the material profile using a defined weight Tension_Control_Solutions.ai



5.3 Calibrating

To change the values for the calibration, please refer to 7.3 Acyclic Data Traffic.

- Connect the first load cell (see 4.5).
- The measuring signal must become positive for loads in measuring direction. If it is negative, the signal lines of the affected load cells must be switches at the terminal block (see 4.5).
- Connect the second load cell.
- The measuring signal must become positive for loads in measuring direction. If it is negative, the signal lines of the affected load cells must be switched at the terminal block (see 4.5).
- Insert material or rope into the machine, without weight/load.
- Perform offset compensation
- Load material or rope with a defined weight (see 5.2).
- Perform calibration

5.4 Gain

Depending on the material wound around the measuring roller, the applied force is not relayed to the sensors 1:1. Thus, the measured force does not correspond to the effectively applied force. To correct for this error, the measured force is amplified using a factor. The factor that is referred to as gain or gain factor is calculated such that the resulting force corresponds to the applied force. The gain is calculated per the following formula:

Option V05



The standard version uses a sensor feedback signal of \pm 9 mV. Measuring amplifiers with the option V05 are designed for a sensor feedback signal of \pm 2.5 mV. The other values in the following description are identical.

Explanatio	Explanations			
Variable	Description			
F _{sys} Digit	Is the system force as binary value after the A/D converter. This value is a constant with value 11'890. It is independent from the number of used load cells. From the user's point of view, this value corresponds to an input signal of 9 mV. The amplifier can measure up to an overload of 37 %.			
Fact N	Effectively applied force at the measuring system in Newtons.			

F _{sys} N	Is the system force of the measuring system in Newtons. It is determined by the number of used load cells. For one load cell, the system force equals the nominal force of the load cell. For two sensors, it is twice as high.
F _{act} Digit	Measured force at the measuring system as binary value after the A/D converter. From the user's point of view, this value corresponds to a voltage in mV, which is relayed by the measuring system to the amplifier.

Example

- System force at 9 mV = 11'890 digit
- 2 load cells with 500 N nominal force each, as per type plate; F_{sys} N = 2 x 500 N = 1'000 N;
- Use of a defined weight of 50 kg (corresponds to approx. 500 N); Fact N = 500 N
- Obtain measured force with suspended weight from the PLC, e.g., Fact Digit = 4'980



Note

The gain factor needs to be calculated for both of the channels individually.

5.5 Limit Value Violations

The amplifier checks the analog input and output for limit value violations. At the input, it is checked using the input voltage, whether the load cell is mechanically overloaded (overload test). The measuring amplifier can measure an overload of 37 %. At the output, it is checked, whether the output voltage depending on the amplified input signal will be above or below the physically possible value. In this case, an overflow and/or underflow is present.

5.5.1 Overload Test

The overload test is performed using the raw value read on the ADC. It has thus not related to any force and can be applied independently from the system force to every load cell.

Test rule:

The FMS load cells deliver 9 mV at the output under nominal force load. In the case of a load up to the mechanical stop, approx. 12.4 mV are output. These values apply, if the load cell is loaded in normal operating direction (red point). In reverse direction, the values are respectively negative. The amplifier checks overload in both directions.

The limit value for overload is fixed set to 12 mV and/or -12 mV. If one of these limit values is reached, the overload status bit is set. The bit is removed again, as soon as the raw value is 0.5 mV below and/or above the triggering limit value.

5.5.2 Overflow and Underflow Test

The overflow and underflow test is performed with the output value that is relayed to the DAC, calculated from the gain. If the output value exceeds the maximum possible value, an overflow is present. If it undercuts the minimum possible value, an underflow is present.

Test rule

The output voltage is between 0 and \pm 10 V. A hysteresis of \pm -10 digits is used for the test so that the error bits do not trigger for every small over- and/or underflow. Thus, the overflow triggers, when the theoretically calculated output value of 10.05 V is reached. For underflow, the value is 0.05 V. When these limit values are reached, the respective bits are set in the status. The bits are removed, as soon as the output value is within the valid range again (above 0.05 V and below 9,95 V).

5.6 Description of the LEDs

	LED	Meaning
13 (4 15 16 9 (0 11 12) FMS_0	L/A IN	Off: no connection to the preceding EtherCAT module On: LINK: connection to the preceding EtherCAT module Flashing: ACT: Communication with the preceding EtherCAT module
• RDY • RUN • ERR	L/A OUT	Off: no connection to the following EtherCAT module On: LINK: connection to the following EtherCAT module Flashing: ACT: Communication with the following EtherCAT module
	RUN	Off: Status of the EtherCAT module is Init Flashes quickly: Status of the EtherCAT module is pre-operational Flashes slowly: Status of the EtherCAT module is safe-operational On: Status of the EtherCAT module is operational
5 6 7 8 0 0 T EtherCAT. EMGZ492.R.ECAT EMGZ492.W.ECAT	ERR	Illuminates in red if no RJ45 plug is connected. Flashes red if communication with the PLC is interrupted.
	RDY	Illuminates in green as soon as the voltage supply is connected and the processor is started.

Figure 7: Signal LEDs on EMGZ492.ECAT EMGZ492_ECAT_Grafik.ai



The measuring amplifiers of the EMGZ492.ECAT series can operate in an EtherCAT[®] network. Here, the amplifier operates as EtherCAT[®] slave with an EtherCAT[®] master (e.g. TwinCAT.

6.1 EtherCAT[®] Interface

EtherCAT[®] is supported. The respective communication profile is selected by the EtherCAT[®] master via the ESI. The EMGZ492.ECAT transfers the actual value in digit and the status/error byte. In addition, parameters, such as offset actual value, gain actual value, filter actual value, filter analog output, as well as scaling analog output can be adjusted.

6.2 System Start

Module parameters are not supported.

6.3 Data Exchange

The EMGZ492.ECAT uses the communication types typical in EtherCAT[®]. Cyclic data traffic is used for the fast transmission of measured data. Acyclic data traffic is used for parameterization. Cyclic data traffic is used for transmitting the limit value violations.



7 Configuration

The EMGZ492.ECAT can be configured via EtherCAT[®].

7.1 Parameter Description

Parameter			
Name	Description		
Unit	Here you select which unit of measurement is used. The label located on the sensor will indicate the nominal force in Newtons.		
	Note:		
	This input will als data.	o affect the unit of the cyclic process	
	lf lb (pound) is se to imperial meas	lected, the system switches from metric uring units.	
	Selection	N, kN, lb, g, kg	
	Specified value	Ν	
Low-pass filter active A	Here, the status of force sensor A is	of the low-pass filter active value for the indicated.	
	This parameter c	annot be accessed via the web interface.	
	Min.	0	
	Max.	1	
	Specified value 1		
	0 = no, inactive, 1 = yes, active		
Offset A	The values deterr procedure are sto [Offset] paramete for the roller weig	nined with the "Offset Compensation" ored in the form of a digital value in the er. The value is used for compensating ght of force sensor A.	
	Min.	-16'000	
	Max.	16'000	
	Specified value	0	
Gain A	The gain factor ended the effective force	nsures that the displayed force matches e on sensor A.	
	Min.	0.100	
	Max.	20.000	
	Specified value	1.000	



Nominal force A	The nominal force indicates the measuring capacity of force sensor A. E.g., if a 500 N load cells is installed 500 N must be entered.	
	Unit	Ν
	Min.	1.00
	Max.	200'000.00
	Specified value	1'000.00
Limit frequency low- pass filter actual value A	equency low- ter actual value The amplifier features a low-pass filter that filt measured value is relayed via EtherCAT®. This used for suppressing undesired interference si are superimposed on the measuring signal. Us parameter, the limit frequency of the filter of f A is adjusted. The lower the limit frequency, th the measuring value.	
	This low-pass filte	er is independent from the output filter.
	Unit	Hz
	Min.	0.1
	Max.	200.0
	Specified value	10.0
Low-pass filter active B	Here, the status of force sensor B is	of the low-pass filter active value for the indicated.
	This parameter ca	annot be accessed via the web interface.
	Min.	0
	Max.	1
	Specified value	1
	0 = no, inactive, 1	L = yes, active
Offset B	The values determined with the "Offset Competence procedure are stored in the form of a digital val [Offset] parameter. The value is used for competence for the roller weight of force sensor B.	
	Min.	-16'000
	Max.	16'000
	Specified value	0



Gain B	The gain factor ensures that the displayed force matches the effective force on sensor B.		
	Min.	0.100	
	Max.	20.000	
	Specified value	1.000	
Nominal force B	The nominal force indicates the measuring capacity force sensor B. E.g., if a 500 N load cells is installed N must be entered.		
	Unit	Ν	
	Min.	1.00	
	Max.	200'000.00	
	Specified value	1'000.00	
Limit frequency low- pass filter actual value B	The amplifier features a low-pass filter that filters the measured value is relayed via EtherCAT [®] . This filter is used for suppressing undesired interference signals that are superimposed on the measuring signal. Using this parameter, the limit frequency of the filter of force senso B is adjusted. The lower the limit frequency, the slower the measuring value.		
	This low-pass filte	er is independent from the output filter.	
	Unit	Hz	
	Min.	0.1	
	Max.	200.0	
	Specified value	10.0	
Low-pass filter analog output active	Here, the status of the low-pass filter for the analog output is indicated.		
	Min.	0	
	Max.	1	
	Specified value	1	
	0 = no, inactive, 1	L = yes, active	

Limit frequency low- pass filter analog output	The amplifier features a low-pass filter that filters the signal of the analog voltage output. This filter is used for suppressing undesired interference signals. Using this parameter, the limit frequency of the filter is adjusted.		
	This low-pass filte filter.	er is independent from the EtherCAT®	
	Unit	Hz	
	Min.	0.1	
	Max.	200.0	
	Specified value	10.0	
Analog output scaling	This parameter determines, for which force the analog output outputs its maximum voltage (10 V).		
	Note:		
	lf lb (pound) is se to imperial meas	lected, the system switches from metric uring units.	
	Unit	Ν	
	Min.	0.1	
	Max.	200'000.00	
	Specified value	1'000.00	

7.2 Cyclic Data Traffic

After a successful system start the EtherCAT[®] master and the assigned EtherCAT[®] slaves can exchange cyclic process data. The table below shows the measured data and how they are transmitted.

Parameter				
Name	Description			
Actual value A in ADC	Value read in via the A/D converter.			
	Data type	int (signed 16 bit)		
	Value range	-16384 to 16383		
	Value format ±#####			
	The value is interpreted as integer without decimal place. E.g. 1000 = 1000 ADC raw value			

FMS



Actual value A in	Filtered actual value converted into Newton		
Newton	Data type	long (signed 32 bit)	
	Value range	±200'000'000	
	Value format	±######.###	
	The value is inter decimal places.	rpreted as decimal number with 3 E.g. 1500 = 1.500 N (1.5 N)	
	Unit	Ν	
Actual value A in	Filtered actual va	alue converted into pound.	
pound	Data type	long (signed 32 bit)	
	Value range	±200'000'000	
	Value format	±######.###	
	The value is interpreted as decimal number with 3 decimal places. E.g. 224820 = 224.820 lb (224.82 lb)		
	Unit	lb	
Actual value A in unit	Filtered actual va	alue converted into configured unit.	
	Data type	long (signed 32 bit)	
	Value range	±200'000'000	
	Value format	±########### for N, kN, kg, or lb	
	The value is interpreted as decimal number with 3 decimal places. E.g. unit set to kN 100000 = 100.000 kN (100kN)		
	Value format	±########### for g	
	The value is interpreted as decimal number with 1 decimal place. E.g. unit set to g 12340 = 1234.0 g (1234 g)		
	Unit	N, kN, g, kg, or lb	
Actual value B in ADC	Value read in via	the A/D converter.	
	Data type	int (signed 16 bit)	
	Value range	-16384 to 16383	
	Value format	±#####	
	The value is inter E.g. 1000 = 100	rpreted as integer without decimal place. 0 ADC raw value	



Actual value B in	Filtered actual value converted into Newton		
Newton	Data type	long (signed 32 bit)	
	Value range	±200'000'000	
	Value format	±#####################################	
	The value is inter decimal places. E	preted as decimal number with 3 E.g. 1500 = 1.500 N (1.5 N)	
	Unit	Ν	
Actual value B in	Filtered actual va	lue converted into pound.	
pound	Data type	long (signed 32 bit)	
	Value range	±200'000'000	
	Value format	±######.###	
	The value is interpreted as decimal number with 3 decimal places. E.g. 224820 = 224.820 lb (224.82 lb)		
	Unit	lb	
Actual value B in unit	Unit Filtered actual va	lb Alue converted into configured unit.	
Actual value B in unit	Unit Filtered actual va Data type	lb alue converted into configured unit. long (signed 32 bit)	
Actual value B in unit	Unit Filtered actual va Data type Value range	lb alue converted into configured unit. long (signed 32 bit) ±200'000'000	
Actual value B in unit	Unit Filtered actual va Data type Value range Value format	lb alue converted into configured unit. long (signed 32 bit) ±200'000'000 ±########## for N, kN, kg, or lb	
Actual value B in unit	Unit Filtered actual va Data type Value range Value format The value is inter decimal places. E (100 kN)	lb alue converted into configured unit. long (signed 32 bit) ±200'000'000 ±########### for N, kN, kg, or lb preted as decimal number with 3 E.g. unit set to kN 100000 = 100.000 kN	
Actual value B in unit	Unit Filtered actual va Data type Value range Value format The value is inter decimal places. E (100 kN) Value format	lb alue converted into configured unit. long (signed 32 bit) ±200'000'000 ±########### for N, kN, kg, or lb preted as decimal number with 3 E.g. unit set to kN 100000 = 100.000 kN ±############# for g	
Actual value B in unit	Unit Filtered actual va Data type Value range Value format The value is inter decimal places. E (100 kN) Value format The value is inter decimal place. E. g)	Ib alue converted into configured unit. long (signed 32 bit) ±200'000'000 ±########## for N, kN, kg, or Ib appreted as decimal number with 3 E.g. unit set to kN 100000 = 100.000 kN ±############# for g appreted as decimal number with 1 g. unit set to g 12340 = 1234.0 g (1234)	



Actual value A + B in	Filtered actual su	m value converted into configured unit.
unit	Data type	long (signed 32 bit)
	Value range	±200'000'000
	Value format	±########### for N, kN, kg, or lb
	The value is inter decimal places. E (100 kN)	preted as decimal number with 3 E.g. unit set to kN 100000 = 100.000 kN
	Value format	±########### for g
	The value is inter decimal place. E. g)	preted as decimal number with 1 g. unit set to g 12340 = 1234.0 g (1234
	Unit	N, kN, g, kg, or lb
Actual value A - B in unit	Filtered actual di configured unit.	fferential value converted into
	Data type	long (signed 32 bit)
	Value range	±200'000'000
	Value format	±########### for N, kN, kg, or lb
	The value is inter decimal places. E (100 kN)	preted as decimal number with 3 E.g. unit set to kN 100000 = 100.000 kN
	Value format	±########### for g
	The value is inter decimal place. E. g)	preted as decimal number with 1 g. unit set to g 12340 = 1234.0 g (1234
	Unit	N, kN, g, kg, or lb
Actual value (A + B)/2 in unit	Filtered actual av unit.	verage value converted into configured
	Data type	long (signed 32 bit)
	Value range	±200'000'000
	Value format	±########### for N, kN, kg, or lb
	The value is inter decimal places. E (100 kN)	preted as decimal number with 3 E.g. unit set to kN 100000 = 100.000 kN
	Value format	±########### for g
	The value is inter decimal place. E. g)	preted as decimal number with 1 g. unit set to g 12340 = 1234.0 g (1234
	Unit	N, kN, g, kg, or lb



7.3 Acyclic Data Traffic

After a successful system start the EtherCAT[®] master the assigned EtherCAT[®] slaves can exchange acyclic requirement data. The following table shows the parameters and commands and how they are transmitted using acyclic data traffic.

To address the parameter group "Force Values Configuration" the index 0x2800 and sub index 0x01 to 0x08 have to be used.

Parameter		
Index 0x2800	Description	
Sub index		
0x01	Unit	
	Access type	R/W
	Parameter command	unit
	Data type	byte (unsigned 8 bit)
	Value range	0 to 4 0=N; 1=kN; 2=Ib; 3=g; 4=kg
	Value format	#



0x02	Offset A	
	Access type	R/W
	Parameter command	offset
	Data type	int (unsigned 16 bit)
	Value range	-16'000 to 16'000
	Value format	±#####
0x03	Gain A	
	Access type	R/W
	Parameter command	gain
	Data type	int (unsigned 16 bit)
	Value range	100 to 20'000
	Value format	##.###
0x04	Nominal force A	
	The nominal force is the the used measuring system	e maximum permissible force of tem.
	Access type	R/W
	Parameter command	Nominal force
	Data type	long (unsigned 32 bit)
	Value range	0 to 200'000'000
	Value format	######.###
	Unit	Ν
0x05	Low-pass filter active A	
	Switch the low-pass filte = on.	r actual value on or off; 0 = off; 1
	Not remanent: The adjust filter is switched on afte	sted value is lost on a restart! This r a restart.
	This parameter cannot b	be accessed via the web interface.
	Access type	R/W
	Parameter command	low-pass filter actual value active (EtherCAT®)
	Data type	byte (unsigned 8 bit)
	Value range	0 to 1
	Value format	#
1		

0x06	Limit frequency low-pase	s filter actual value A
	Limit frequency of the low-pass filter for the actual value outputted via EtherCAT [®] .	
	Access type	R/W
	Parameter command	limit frequency low-pass filter actual value (EtherCAT®)
	Data type	int (unsigned 16 bit)
	Value range	1 to 2'000
	Value format	###_#
	Unit	Hz
0x07	Offset adjustment A	
	Determine and store off without material tensior	set. The system is set to zero 1.
	Access type	W
	Parameter command	offset adjustment
	Data type	byte (unsigned 8 bit)
	Value range	0 to 1
	Value format	#
0x08	Calibration A	
	Calibrates the amplifier handed over here. It mu	to the weight in Newton, which is st match the suspended weight.
	Access type	W
	Parameter command	calibration
	Data type	long (signed 32 bit)
	Value range	0 to 200'000'000
	Value format	######.###
	Unit	Ν
0x09	Offset B	
	Access type	R/W
	Parameter command	offset
	Data type	int (unsigned 16 bit)
	Value range	-16'000 to 16'000
	Value format	±#####

FMS



0x0A	Gain B	
	Access type	R/W
	Parameter command	gain
	Data type	int (unsigned 16 bit)
	Value range	100 to 20'000
	Value format	##.###
0x0B	Nominal force B	
	The nominal force is the the used measuring system	maximum permissible force of tem.
	Access type	R/W
	Parameter command	Nominal force
	Data type	long (unsigned 32 bit)
	Value range	0 to 200'000'000
	Value format	######.###
	Unit	Ν
0x0C	Low-pass filter active B	
	Switch the low-pass filte = on.	r actual value on or off; 0 = off; 1
	Not remanent: The adjust filter is switched on afte	sted value is lost on a restart! This r a restart.
	Access type	R/W
	Parameter command	low-pass filter actual value active (EtherCAT®)
	Data type	byte (unsigned 8 bit)
	Value range	0 to 1
	Value format	#

0x0D	Limit frequency low-pass	filter actual value B
	Limit frequency of the lo outputted via EtherCAT®	w-pass filter for the actual value
	Access type	R/W
	Parameter command	limit frequency low-pass filter actual value (EtherCAT®)
	Data type	int (unsigned 16 bit)
	Value range	1 to 2'000
	Value format	###.#
	Unit	Hz
0x0E	Offset adjustment B	
	Determine and store offs without material tension	set. The system is set to zero
	Access type	W
	Parameter command	offset adjustment
	Data type	byte (unsigned 8 bit)
	Value range	0 to 1
	Value format	#
0x0F	Calibration B	
	Calibrates the amplifier the handed over here. It must	to the weight in Newton, which is at match the suspended weight.
	Access type	W
	Parameter command	calibration
	Data type	long (signed 32 bit)
	Value range	0 to 200'000'000
	Value format	######.###
	Unit	Ν

Explanation of access types: R = Read, W = Write, R/W = Read and Write.

To address the parameter group "Analog Output Configuration" you have to use index 0x2820 and subindex 0x01 to 0x04.

Parameter	
Index 0x2820	Description
Sub index	



0x01	Output value	
	0 = (A + B)/2	
	1 = A + B	
	2 = A - B	
	3 = A	
	4 = B	
0x02	Analog output scaling	
	Determines, at which for maximum value of 10 V	rce the analog output outputs the
	Access type	R/W
	Parameter command	analog output scaling
	Data type	long (unsigned 32 bit)
	Value range	100 to 200'000'000
	Value format	######.###
	Unit	Ν
0x03	Low-pass filter analog or	utput active
	Switch the low-pass filte 1 = on.	r analog output on or off; 0 = off;
	Not remanent: The adjus filter is switched on afte	sted value is lost on a restart! This r a restart.
	Access type	R/W
	Parameter command	low-pass filter analog output active
	Data type	byte (unsigned 8 bit)
	Value range	0 to 1
	Value format	#

0x04	Limit frequency low-pase	s filter analog output
	Limit frequency of the low-pass filter for the actual value outputted via the analog output.	
	Access type	R/W
	Parameter command	limit frequency low-pass filter analog output
	Data type	int (unsigned 16 bit)
	Value range	1 to 2'000
	Value format	###.#
	Unit	Hz

Explanation of access types: R = Read, W = Write, R/W = Read and Write.





8 EtherCAT[®] Communication

The acyclic data exchange is provided according to the ESI file

8.1 Services and Protocols

The following services and protocols are used:

- SDO client and server side protocol (CoE)
- File Access over EtherCAT®(FoE)

All other services required for EtherCAT® are permissible as well.

The services above can be used with the EMGZ492.ECAT at any time.



9 Dimensions



Figure 8: EMGZ492.R.ECAT housing for DIN rail mounting EMGZ492_ECAT_Grafik.ai







10 Technical Data

Technical data	
Number of channels	2 channel for 2 or 4 sensors
Excitation voltage	5 VDC
Sensor feedback signal	± 9 mV (max. 12.5 mV)
	Option V05 ± 2.5 mV
A/D converter resolution	± 32'768 digit (16 bit)
D/A converter resolution	0 to 4'096 (12 bit)
Measuring inaccuracy	< 0.05 % FS
Connector for interface	EMGZ 492.R.ECAT: 2 x RJ-45
	EMGZ 492.W.ECAT: 2 x M 12 4-pole, D-coded
Parameterization	via EtherCAT®
Protection class	IP 20 (.R version)
	IP 65 (.W version)
Power supply	24 VDC (18 to 36 VDC)
Power consumption	5 W
Temperature range	-10 to +50 °C (14 to 122 °F)
Weight	370 g / 0.82 lbs (.R version);
	470 g / 1.04 lbs (.W version)

EtherCAT [®] characteristics	
Cycle time	≥ 1 ms in Free Run Mode
Baud rate	100 Mbit /s
Cyclic process data	PDO with fixed mapping
Acyclic communication	SDO Master-Slave
Supported protocols	SDO client and server side protocol (CoE); File Access over EtherCAT (FoE)
CoE (CAN application layer over EtherCAT)	SDO Upload, SDO Download, SDO Information Service (Object Dicti onary)
Mailbox Size	Fix length of 128 Byte
SII (Slave Information Interface)	4 kB
Туре	Complex Slave
FMMUs	8
SYNC Manager	4
Explicit Device Identification	Set Device Identification by Configuration Tool
Applied standards	The device is foreseen to be used in industrial electromagnetic environment.
	IEC 61326-2-3:2020 IEC 61326-2-3:2012 (ed.2) IEC 61326-1:2012 (ed.2) IEC 61326-1:2020 (ed.3) IEC 61000-6-2:2016 IEC 61000-6-3:2020











FMS Force Measuring Systems AG Aspstrasse 6 8154 Oberglatt (Switzerland) Tel. +41 44 852 80 80 Fax +41 44 850 60 06 info@fms-technology.com www.fms-technology.com

FMS USA, Inc. 2155 Stonington Avenue Suite 119 Hoffman Estates,, IL 60169 (USA) Tel. +1 847 519 4400 Fax +1 847 519 4401 fmsusa@fms-technology.com